


US 141821XX







LED LUMINAIRE FRAME - FOR NON-IC REMOTE DRIVER

- Read all instructions.
- Save these instructions.

BASIC SAFETY PRECAUTIONS

- Suitable for damp locations.
- Access above ceiling required.



PREVENTING ELECTROSTATIC DAMAGE

A discharge of static electricity may damage sensitive components. Always be properly grounded when touching leads or circuitry inside the luminaire. Use a wrist strap connected by a ground cord to the housing. Avoid touching the light sources with bare hands.



LIGHT SOURCE - DO NOT TOUCH LED

Touching the LED can result in permanent damage of the light source. The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.

LIGHT ENGINES, POWER UNITS & ACCESSORIES

For latest version of all light engines, power units and available accessories check www.supermodular.us or connect with your sales contact.

