

Smart Cake 82 Adjustable LED GE


133201XX_B1_133202XX_B1_133211XX_B1_133212XX_B1_133221XX_B1_133222XX_B1




ELECTRICAL SPECS LED-FIXTURE			
Drive Current (mA)	Forward Voltage		Power
	min (Vf)	max (Vf)	(W)
350	13,2	15,0	5,0
500	13,7	15,4	7,2
• RED		⊖ BLACK	
For ser	ial connectior	n. respect pola	ritv!

Not suited for connection to mains voltage. Combine with a Modular LED-driver.











3

install : Twist clockwise uninstall : Twist counterclockwise





4



Touching the LED can result in permanent damage of the light source. The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.

PREVENTING ELECTROSTATIC DAMAGE

A discharge of static electricity may damage sensitive components. Always be properly grounded when touching leads or circuitry inside the luminaire. Use a wrist strap connected by a ground cord to the housing. Avoid touching the light sources with bare hands.

DRIVERS & ACCESSORIES

ESD

For latest version of driver matrix and available accessories check www.supermodular.com or connect with your sales contact.



01 - 27/01/2022