




139551XX 139552XX 139554XX 139555XX

 **MOUNT LED DRIVER
REMOTE AND ACCESSIBLE**



SCREWS NOT INCLUDED




ELECTRICAL SPECS LED

Drive Current (mA)	Forward Voltage		Power (W)
	min (Vf)	max (Vf)	
350	30,8	37,6	12

+ RED **-** BLACK

For serial connection, respect polarity!
Not suited for connection to mains voltage.
Combine with a Modular LED-driver.

SERIAL CONNECTION 1 DRIVER



Always use a serial connection for multiple luminaires on a single driver!
Only use luminaires with the same input ratings!


ELECTRICAL SPECS LED

Drive Current (mA)	Forward Voltage		Power (W)
	min (Vf)	max (Vf)	
350	15,4	18,8	6

+ RED **-** BLACK

For serial connection, respect polarity!
Not suited for connection to mains voltage.
Combine with a Modular LED-driver.


 1 LED 1 DRIVER




Always use a serial connection for multiple luminaires on a single driver!
Only use luminaires with the same input ratings!

For latest version of driver matrix and available accessories check www.supermodular.com or connect with your sales contact.




driver driver



click



5	UNINSTALL
---	-----------



 ONLY TO BE INSTALLED OUTSIDE ARM'S REACH

