




# Track 48V Modupoint 1x LED

134569XX\_134570XX\_134571XX\_134572XX



## 1.1 INSTALLATION





## 1.2 INSTALLATION




## 1.3 INSTALLATION





## 2.1 UNINSTALL



## 2.2 UNINSTALL




## 2.3 UNINSTALL




⚠ Turn off power before taking out luminaires from the track system


## ELECTRICAL




ADAPTER ORIENTATION



ADAPTER ORIENTATION



ADAPTER ORIENTATION



## PREVENTING ELECTROSTATIC DAMAGE

A discharge of static electricity may damage sensitive components. Therefore do not touch the LED nor the stripped parts of the wires with bare hands. Always be properly insulated by using ESD gloves.

## DRIVERS & ACCESSORIES

For latest version of driver matrix and available accessories check [www.supermodular.com](http://www.supermodular.com) or connect with your sales contact.

