



Nyto Track 48V Adjustable 60 1x LED

140300XX_140301XX_140302XX_140303XX_140304XX_140305XX_140306XX_140307XX_140308XX_140309XX_140310XX_140311XX_140312XX_140313XX_140314XX_140315XX_140316XX_140317XX_140318XX_140319XX



1.1 INSTALLATION



ONLY TO BE INSTALLED OUTSIDE ARM'S REACH




1.2 INSTALLATION




VOLTAGE	48 V
POWER super spot (1-10V)	11 W
POWER super spot (Dali)	10,5 W
POWER spot (1-10V)	13 W
POWER spot (Dali)	13,6 W
POWER medium, flood, wide flood (1-10V)	21,3 W
POWER medium, flood, wide flood (DALI)	18,9 W


2.1 UNINSTALL




Turn off power before taking out luminaires from the track system




2.2 UNINSTALL



ELECTRICAL



ADAPTER ORIENTATION



ADAPTER ORIENTATION



Replace protective shield when broken. The luminaire shall only be used complete with its protective shield.
Reference number: 1017031 (super spot), 1016963 (spot), 1016930 (medium), 1016928 (flood), 1016926 (wide flood).



LIGHT SOURCE - DO NOT TOUCH LED

Touching the LED can result in permanent damage of the light source. The light source and/or driver contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.



PREVENTING ELECTROSTATIC DAMAGE

A discharge of static electricity may damage sensitive components. Therefore do not touch the LED nor the stripped parts of the wires with bare hands. Always be properly insulated by using ESD gloves.

DRIVERS & ACCESSORIES

For latest version of driver matrix and available accessories check www.supermodular.com or connect with your sales contact.