



Nomad 2x for LED AR111 Tre dim GI

12352202_12352205_12352209


1




CONNECT LAMPS WITH THE 2 SCREWS





2




SCREWS NOT INCLUDED



3




4



TO BE COMBINED WITH

Advised to use 70008066 / 70008067



LIGHT SOURCE - DO NOT TOUCH LED

Touching the LED can result in permanent damage of the light source. The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.



PREVENTING ELECTROSTATIC DAMAGE

A discharge of static electricity may damage sensitive components. Always be properly grounded when touching leads or circuitry inside the luminaire. Use a wrist strap connected by a ground cord to the housing. Avoid touching the light sources with bare hands.