



Smart Cake/Kup/Lotis 82 Adj LED DE

133101XX_133102XX_133111XX_133112XX_133121XX_133122XX_133201XX_133202XX_133211XX_133212XX_133221XX_133222XX_133301XX_133302XX_133311XX_133312XX_133321XX_133322XX


SMART CAKE ADJ 82





SMART KUP ADJ 82



SMART LOTIS ADJ 82



1




ELECTRICAL SPECS LED-FIXTURE



Drive Current (mA)	Forward Voltage		Power (W)
	min (Vf)	max (Vf)	
350	16,5	19,2	6,2
500	17,1	19,8	9,2

+ RED **-** BLACK



For serial connection, respect polarity!
Not suited for connection to mains voltage.
Combine with a Modular LED-driver.




2



3



⚠ SERIAL CONNECTION:



Always use a serial connection for multiple luminaires on a single driver!
Only use luminaires with the same input ratings!



LIGHT SOURCE - DO NOT TOUCH LED

Touching the LED can result in permanent damage of the light source. The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.



PREVENTING ELECTROSTATIC DAMAGE

A discharge of static electricity may damage sensitive components. Therefore do not touch the LED nor the stripped parts of the wires with bare hands. Always be properly insulated by using ESD gloves.

DRIVERS & ACCESSORIES

For latest version of driver matrix and available accessories check www.supermodular.com or connect with your sales contact.